

Troubleshooting for UV unit

V. Cause and Action for alarm/trip relating to UV Chamber(unit)

F. UV CHAMBER TEMPERATURE SENSOR FAIL

Trip indicates that the UV temperature sensor output is out of range.

Cause	Description	Action
1	Temperature sensor failure	1
2	Poor or no wire connection	1

Troubleshooting for UV unit

V. Cause and Action for alarm/trip relating to UV Chamber(unit)

F. UV CHAMBER TEMPERATURE SENSOR FAIL

Cause 1: Temperature sensor failure

Action 1



If necessary, replace Temperature Sensor in UV Chamber


Troubleshooting for UV unit

V. Cause and Action for alarm/trip relating to UV Chamber(unit)

F. UV CHAMBER TEMPERATURE SENSOR FAIL

Cause 2: Poor or wire connection

Action 1



Check if all the electric wires are connected and tightened properly according to the electric drawings.